

**COLOR STARS**  
 1.0 (9600 8 N 1)

Commands are repeated out of the serial port to pass to the next controller or device.  
 All commands must be terminated with a carriage return. You can use \r for this.

**COLOR STARS COMMANDS**  
 1.0

COMMAND	MODE
psf	Kaleidoscope
psl	Chroma Sweep
psw	Iridescent White
psvi	Party Mode
psp	Color Wheel
psr	Red Sparkle
psg	Green Sparkle
psb	Blue Sparkle
psm	Magenta Sparkle
psc	Cyan Sparkle
psy	Gold Sparkle
psrd	Random Strobe
psld	Solid Color Mode
psdmXXX	Dim Level Command (1-100%)
pspdXXX	Sparkle Speed Command
psetXXX	Solid Color Set
pso	Off
globaloff	Stars Off
ptest	LED Test Mode

**COLOR STARS BUTTON PROGRAMS**  
 1.0

BUTTON 1 CYCLE	MODE
psf	Kaleidoscope
psl	Chroma Sweep
psw	Iridescent White
psvi	Party Mode
psp	Color Wheel
psr	Red Sparkle
psg	Green Sparkle
psb	Blue Sparkle
psm	Magenta Sparkle
psc	Cyan Sparkle
psy	Gold Sparkle
psrd	Random Strobe
Button 2	Off

**COLOR STARS DIP SWITCH SETTINGS**  
 1.0

MODE	SWITCH 1	SWITCH 2	SWITCH 3
Kaleidoscope	Up	Up	Up
Chroma Sweep	Down	Up	Up
Iridescent White	Up	Down	Up
Party Mode	Down	Down	Up
Color Wheel	Up	Up	Down
Red Sparkle	Down	Up	Down
Green Sparkle	Up	Down	Down
Blue Sparkle	Down	Down	Down

**NOTE:** DIP Switch 4 up is Full Brightness, down is Dim to 30%